










# Assembly Instructions

MODEL NO. LEX-EC-SR090-60SL  
LEX-EC-SR100-60SL

REV-1





**HARDWARE LIST**

**TOOLS REQUIRED**



<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>	<b>G</b>		
							Hand Drill	Allen Key 4mm
*Hardware from Lex End Cross Beam				*Hardware from Rectangular Beam				

**STEP 1**

**STEP 2**



**COMPLETED ASSEMBLY**



**IMPORTANT NOTE:**

- 1) Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- 2) Check to be sure that you have all parts and hardware.
- 3) Remove all wrapping materials, including staples & packing straps before you start to assemble.
- 4) Keep all hardware parts out of reach of children.
- 5) If the product is not working properly, is missing a part, is damaged, or if you have any questions, please call customer service hotline before returning. To smoothen the process, kindly provide the invoice number, SO number and photo of damaged part or missing pieces to the handler.
- 6) Customer Service Hotline : +6 03 - 3392 6888. For further assembly instructions, please email us at [info@versalink.com](mailto:info@versalink.com)

